


Meter Readings


imageRUNNER ADVANCE DX



Press the 123 icon in the bottom right corner of the copiers control panel



The meter readings are now displayed on screen



Meter Readings

imageRUNNER ADVANCE



Press the meter reading button is located on the side of the control panel next to the number 3



The meter readings are now displayed on screen

